

Stand type-> Wall mounted type replacement method


Take the product out of the shipping box, read the User Manual of the previous pages first, then do the following:




<Unpacking>



*Mating parts



(E)




Use screws (A) to fasten holder brackets to the air purifier.




This is the image after the product and the holder brackets are combined.

Use the screw anchors when the wall has the same or greater strength as a concrete wall.




Mark where the screw anchors for the wall bracket are drilled.




Recommended height 160-170cm at a minimum


Distance from the wall 10cm at a minimum




Drill out three holes.



Gently tap the screw anchors (B) in with a hammer, and secure them to the wall using screws (©) and washers (D).



Mount the main body onto the wall bracket in the direction shown (two arrows) in the picture.





Finish the installation by tightening the screws (E) into the sides of the product.

Wall mounted type -> Stand type replacement method

For the kit replacement method, download it from DYNAIR website at www.dynair.co.kr.

*Mating parts








Unscrew the bottom of the product.




Put the unscrewed screw into the groove of the stand base, then recombine

with the main body.



The shape of the stand base combined is seen.

If losing a component screw, the screws equipped with the existing products are also the same parts, so use them with confidence.



Loosen the combined screw on the back, separate the mounting bracket.

Combine with the stand by using the separated screws.

Call Center: 1833-2046 / Weekdays 09:30 ~ 17:00